




MODEL

EH63D

EH64D

EH65D

**INSTRUCTIONS FOR USE  
MANUEL D'UTILISATION  
BEDIENUNGSANLEITUNG  
GEBRUIKSAANWIJZING  
MANUAEL D'USO E MANUTENZIONE**



英·仏·独·蘭·伊

ISSUE EMD-EU1213

2ZZ9990033













**Robin Engines**



# CONTENTS

|                                   |    |
|-----------------------------------|----|
| 1. SAFETY PRECAUTIONS .....       | 1  |
| 2. COMPONENTS .....               | 4  |
| 3. PRE-OPERATION CHECKS .....     | 5  |
| 4. BATTERY INSTALLATION .....     | 7  |
| 5. OPERATING YOUR ENGINE .....    | 9  |
| 6. EASY TROUBLESHOOTING .....     | 12 |
| 7. MAINTENANCE SCHEDULE .....     | 14 |
| 8. "HOW-TO" MAINTENANCE .....     | 16 |
| 9. PREPARATIONS FOR STORAGE ..... | 19 |
| 10. SPECIFICATIONS .....          | 20 |


# SYMBOLS

|   |   |   |   |
|---|---|---|---|
|    | <p><i>Read the owner's manual.</i></p>  |   |   |
|    | <p><i>Stay clear of the hot surface.</i></p>  |   |   |
|    | <p><i>Exhaust gas is poisonous.<br/>Do not operate in an unventilated area.</i></p> |   |   |
|    | <p><i>Stop the engine before refueling.</i></p>                                     |   |   |
|   | <p><i>Fire, open flame and smoking prohibited.</i></p>                              |   |   |
|  | <p><i>On (Run)</i></p>  |  | <p><i>Plus ;<br/>positive polarity</i></p>        |
|  | <p><i>Off (Stop)</i></p>  |  | <p><i>Battery</i></p>                             |
|  | <p><i>Engine oil</i></p>  |  | <p><i>Engine start (Elec-<br/>tric start)</i></p> |
|  | <p><i>Add oil</i></p>   |   |   |

# 1. SAFETY PRECAUTIONS

---

Please make sure you review each precaution carefully.



## EXHAUST PRECAUTIONS

Never inhale exhaust gas.

It contains carbon monoxide, a colorless, odorless and extremely dangerous gas which can cause unconsciousness or death.

Never operate the engine indoors or in a poorly ventilated area, such as tunnel, cave, etc.

Exercise extreme care when operating the engine near people or animals.

Keep the exhaust pipe free of foreign objects.

## REFUELING PRECAUTIONS

Be sure to stop the engine prior to refueling.

Do not overfill the fuel tank.

If fuel is spilt, wipe it away carefully and wait until the fuel has dried before starting the engine.

After refueling, make sure that the fuel cap is secured to prevent spillage.




## FIRE PREVENTION

Do not operate while smoking or near an open flame.

Do not use around dry brush, twigs, cloth rags, or other flammable materials.

Keep the engine at least 3 feet (1 meter) away from buildings or other structures.

Keep the engine away from flammables and other hazardous materials (trash, rags, lubricants, explosives).



## PROTECTIVE COVER

**Place the protective covers over the rotating parts.**

If rotating parts such as the drive shaft, pulley, belt, etc. are left exposed, they are potentially hazardous.


To prevent injury, equip them with protective covers or shrouds.

**Be careful of hot parts.**

The muffler and other engine parts become very hot while the engine is running or just after it has stopped. Operate the engine in a safe area and keep children away from the running engine.

Never make adjustments on the machinery while it is connected to the engine, without first removing the ignition cable from the spark plug. Turning the crankshaft by hand during adjusting or cleaning might start the engine, and the machinery with it, causing serious injury to the operator.

Never run the engine with governor disconnected, or operate at speeds in excess of 3600 rpm load.



## SURROUNDINGS

Operate the engine on a stable, level surface free of small rocks, loose gravel, etc.

### NOTE


Operating the engine at a steep incline may cause seizure due to improper lubrication even with a maximum oil level.

---

**Drain the fuel when transporting the engine.**

**Do not move the engine while in operation when it has been removed from the equipment.**

Keep the unit dry (do not operate it in rainy conditions).



## **PRE-OPERATION CHECKS.**

Carefully check fuel hoses and connections for looseness and fuel leakage. Leaking fuel creates a potentially dangerous situation.

Check bolts and nuts for looseness. A loose bolt or nut may cause serious engine trouble.


Check the engine oil daily and refill if necessary.

Check the fuel level and refill if necessary.



Do not overfill the tank.

Wear snug fitting working clothes when operating the engine.

Loose aprons, towels, belt, etc., may be caught in the engine or drive train, causing a dangerous situation.



# 2. COMPONENTS




## REMARKS :

Fuel tank, valve (sediment bowl type is recommended), fuel hoses, and fuel filter are required for connecting fuel source to carburetor.

A battery rated at 12V-30AH or larger with the specified cable are required for electric starter operation. Make the proper electrical wiring arrangements before normal engine operation. See Section 4 in this manual for instructions.



# 3. PRE-OPERATION CHECKS



## CHECK ENGINE OIL (DAILY)

Before checking or refilling engine oil, be sure the engine is not running and is located on a stable, level surface.

If the oil level is below the lower level line on the oil gauge, refill with the proper oil (see table) to the upper level.

### OIL CAPACITY : 1.55 liter

When filling oil in the engine, keep the engine level and fill the oil up to the upper mark of the oil gauge. Measure the oil level with the oil gauge plugged in position.


After an oil change, run the engine, and recheck the oil level. The oil level may drop a little as the oil fills the oil filter. Fill the oil up to the upper mark of the oil gauge.

Change oil if it is contaminated. (See page 14 Maintenance Schedule.)

Use class SE, SF (API classification) or higher grade oil.

If multi-grade oil is used, oil consumption tends to increase when the ambient temperature is high.

|                     |        |     |    |    |    |    |       |
|---------------------|--------|-----|----|----|----|----|-------|
| Single grade        | 5W     |     |    |    |    |    |       |
|                     | 10W    |     |    |    |    |    |       |
|                     | 20W    |     |    |    |    |    |       |
|                     | #20    |     |    |    |    |    |       |
|                     | #30    |     |    |    |    |    |       |
|                     | #40    |     |    |    |    |    |       |
| Multi grade         | 10W-30 |     |    |    |    |    |       |
|                     | 10W-40 |     |    |    |    |    |       |
| Ambient temperature | -20    | -10 | 0  | 10 | 20 | 30 | 40    |
|                     | -4     | 14  | 32 | 50 | 68 | 86 | 104 ℞ |



## CHECK FUEL

### **⚠ WARNING**

**Do not refuel while smoking, near an open flame or other potential hazards.**

The fuel tank shall be provided separately, because the engine is not equipped with a fuel tank.

A fuel valve and fuel filter should be connected between the fuel tank and fuel pump.

Securely connect with fuel hoses to the fuel pump to prevent leakage.

Fuel tanks may be mounted up to .66 meters (2 feet) below the carburetor.

If the fuel tank is mounted above the carburetor, a fuel shut off valve must be connected between the fuel tank and fuel pump. The fuel valve must be shut off when the engine is not operating to prevent fuel from flooding the carburetor.

A serious accident may occur if the fuel hose comes off. Properly secure the fuel line connections by completely inserting the hose onto the fittings and securing the connection with a hose clamp.


Use unleaded gasoline only.

Stop the engine and close the fuel valve before filling the fuel tank.

Wipe off any spilled fuel before starting the engine.

# 4. BATTERY INSTALLATION

For electric starter operation, proper electric wiring arrangements are needed before normal engine operation.



## PARTS NEEDED


Use a battery rated 12V-30AH or larger.

Use a proper cable and ground wire to connect battery and key switch and magnetic switch.

## BATTERY CABLE

| CABLE LENGTH    | CABLE DIA. | WIRE GAUGE     |     |      |
|-----------------|------------|----------------|-----|------|
|                 |            | AWG(BS)<br>BWG | SAE | JIS  |
| Less than 1.5 m | 7.3 mm     | 1              | 6   | AV15 |
| 1.5 m to 2.5 m  | 8.5 mm     | 0              | 4   | AV20 |
| 2.5 m to 4.0 m  | 10.8 mm    | 3/0            | 2   | AV30 |

GROUND WIRE, use a flat braided wire of 0.03 sq. in. or larger sectional area. (SAE GAUGE 4)




## KEY SWITCH CABLE

| CABLE LENGTH    | CABLE DIA. | WIRE GAUGE |     |        |
|-----------------|------------|------------|-----|--------|
|                 |            | AWG(BS)    | BWG | JIS    |
| Less than 1.5 m | 1.5 mm     | 14         | 16  | AV1.25 |
| 1.5 m to 3.0 m  | 1.9 mm     | 12         | 14  | AV2    |
| 3.0 m to 5.0 m  | 2.4 mm     | 10         | 13  | AV3    |

## WIRING

Connect positive terminal of electric starter and positive terminal of the battery with battery cable.


Ground negative terminal of the battery to the body of engine or machine with ground wire.



### NOTE

Tighten bolts and nuts on terminals securely so they will not be loosened by vibration.

## WIRING DIAGRAM



Optional hardware shown by dotted lines. Select wires of proper gauge and connect battery as shown by the dotted line in the wiring diagram.

# 5. OPERATING YOUR ENGINE

## STARTING

### FUEL VALVE


1

(Provided by the equipment manufacturer)

Open the fuel valve.

### CHOKE KNOB

3




Pull the choke knob.

If the engine is cold or the ambient temperature is low, pull the choke knob fully.

If the engine is warm or the ambient temperature is high, pull the choke knob half-way, or keep it fully open.

### SPEED CONTROL LEVER


2



Set the speed control lever 1/3 of the way towards the high speed position.

### ELECTRIC STARTER

4



Turn the key switch to the "START" position.


Do not operate the electric starter continuously for more than 5 seconds, even if the engine does not start.

If the engine failed to start, set the key to the "RUN" position and wait for about 10 seconds before retrying.

Never turn the key switch to the "START" position while engine is running.

## CHOKE KNOB

5




After starting the engine, gradually open choke by pushing the choke knob and finally keep it fully opened.


Do not fully open the choke immediately when the engine is cold or the ambient temperature is low, because the engine may stop.

## RUNNING

### SPEED CONTROL LEVER



After the engine starts, set the speed control lever at the low speed position and warm it up without load for a few minutes.



Gradually move the speed control lever toward the high speed position and set it at the required engine speed.


#### NOTE :

Whenever high speed operation is not required, slow the engine down (idle) by moving the speed control lever to save fuel and extend engine life.

## STOPPING

### SPEED CONTROL LEVER

1



Set the speed control lever at the low speed position and allow the engine to run at low speed for 2 or 3 minutes before stopping.


### FUEL VALVE

3

Close the fuel valve.

### ELECTRIC STARTER

2



Turn the key switch to the "STOP" position.

### STOPPING ENGINE WITH THE FUEL VALVE

Close the fuel valve while the engine is running and wait until the engine stops.

Set the key switch to the "STOP" position after stopping the engine.

This procedure eliminates the fuel from the carburetor.

Avoid allowing the fuel to remain in the carburetor over long periods, or the passages of the carburetor may become clogged and malfunctions may result.

# 6. EASY TROUBLESHOOTING

## WHEN ENGINE WILL NOT START:

Perform the following checks before you take the engine to your Robin dealer.

If you still have trouble after completing the checks, take the engine to your nearest Robin dealer.

## Is there enough compression?


If the spark plug is loose, tighten it.

## Is the spark plug wet with gasoline?

1. Choke (close choke lever) and slowly start the engine for 2 or 3 seconds.  
Remove the plug and check if its electrode is wet. If the electrode is wet, fuel is well supplied to your engine.
2. When the electrode is dry, check to find where the fuel is restricted.  
(Check the fuel intake of the carburetor and fuel strainer intake.)
3. In case the engine does not start with well supplied fuel, try using fresh fuel.

### **WARNING**


**Wipe off spilled fuel carefully before checking the spark plug. Place spark plug as far away from spark plug hole as possible. Do not hold spark plug by hand while checking.**



## Is there a strong spark across the electrode?

1. Remove the spark plug and connect it to the plug cap.  
Turn key switch to START position while grounding spark plug against engine body.
2. Try with a new spark plug if the spark is weak or there is no spark.
3. The ignition system is faulty if there is no spark with a new spark plug.  
Take your engine to your nearest Robin dealer.





## **Is your battery well charged ?**


Check the battery, it may be discharged and unable to operate the electric starter.

Consult your nearest dealer or service shop.

# 7. MAINTENANCE SCHEDULE

## DAILY INSPECTION

Before running the engine, check the following service items.



## PERIODIC MAINTENANCE

Periodic maintenance is vital to safe and efficient operation of your engine.


Check the table below for periodic maintenance intervals.

The following chart is based on the normal engine operation schedule.

**(Periodic Maintenance Schedule table)**

| Maintenance Items                          | Every 8 hours (daily)          | Every 50 hours | Every 200 hours | Every 500 hours | Every 1000 hours |
|--|--------------------------------|----------------|-----------------|-----------------|------------------|
| Clean engine and check bolts and nuts      | ● (Daily)                      |                |                 |                 |                  |
| Check and refill engine oil                | ● (Refill daily to fuel level) |                |                 |                 |                  |
| Change engine oil                          |                                | ●              |                 |                 |                  |
| Check battery electrolyte fluid level      |                                | ●              |                 |                 |                  |
| Clean spark plug                           |                                | ●              |                 |                 |                  |
| Clean air cleaner                          |                                | ●              |                 |                 |                  |
| Clean fuel strainer                        |                                |                | ●               |                 |                  |
| Replace air cleaner element                |                                |                | ●               |                 |                  |
| Clean and adjust spark plug and electrodes |                                |                | ●               |                 |                  |
| Replace engine oil filter                  |                                |                | ●               |                 |                  |
| Clean carburetor                           |                                |                |                 | ●               |                  |
| Clean cylinder head                        |                                |                |                 | ●               |                  |
| Clean engine base (oil pan)                |                                |                |                 | ●               |                  |
| Check and adjust valve seats               |                                |                |                 | ●               |                  |
| Adjust valve clearance                     |                                |                |                 | ●               |                  |
| Replace spark plug                         |                                |                |                 | ●               |                  |
| Replace fuel line                          |                                |                |                 |                 | ●                |
| Overhaul engine if necessary               |                                |                |                 |                 | ●                |

# 8. "HOW-TO" MAINTENANCE



## INSPECTING THE SPARK PLUG


Clean off carbon deposits on the spark plug electrode using a plug cleaner or wire brush.

Check electrode gap.

Adjust gap to : 0.7mm to 0.8mm

Use a proper spark plug :

**NGK : BP6ES**



## ENGINE OIL CHANGE

Initial oil change

• • • • • After 20 hours of operation

Thereafter

• • • • • Every 50 hours of operation

1. When changing oil, stop the engine and loosen the drain plug.
2. Re-install the drain plug before refilling oil.
3. Refer to the recommended oil table on page 5.
4. Always use the best grade and clean oil. Contaminated oil, poor quality oil and shortage of oil cause damage to engine or shorten the engine life.


**OIL CAPACITY : 1.55 liter**

## ENGINE OIL FILTER REPLACEMENT

Initial engine oil filter replacement should be performed after 20 hours of operation. Thereafter replace the engine oil filter every 200 hours.

When installing a new oil filter, apply oil to O-ring, attach the oil filter in position and tighten 2/3 turns by hand or with wrench after touching the O-ring to the sealing surface of engine.

Run the engine for a minute ; stop the engine and check for oil leakage around the oil filter and recheck the oil level.



### **⚠ CAUTION**

To prevent injury, pay attention to the spilled hot engine oil when replacing engine oil filter.

## CLEANING AIR CLEANER



A dirty air cleaner element will cause starting difficulty, power loss, engine malfunctions, and shorten engine life extremely.

Always keep the air cleaner element clean. Replaced the air cleaner element set more often in dusty environments.

The air cleaner paper inner element and urethane foam outer element can be removed after removing knob and air cleaner cover. When installing, set the paper element and urethane foam on the air cleaner base. Check that the grommet is in position, and then install the cover with knob tightened securely.


### Urethane Foam cleaning

Wash and clean the urethane foam in kerosene. Saturate in a mixture of 3 parts kerosene and 1 part engine oil, and then squeeze to remove excess oil. Clean or replace the urethane foam element every 50 hours. (more often in dusty environments)



### Paper element


Clean by tapping gently to remove dirt and blow off dust. Never use oil. Clean or replace the paper element every 50 hours of operation, and replace element set every 200 hours or once a year.



**Clean and replace air cleaner elements more often when operating in dusty environments.**

## CHECKING BOLTS, NUTS AND SCREWS

Retighten loose bolts and nuts. Check for fuel and oil leaks. Replace damaged parts with new ones. Keep safety in your mind.




## FUEL HOSE REPLACEMENT

### **WARNING**

**Take extreme caution when replacing fuel hose ; gasoline is flammable.**

Replace the fuel hose every 1,000 hours or every year. If fuel hose leak is found, replace the fuel hose immediately.




## CHECKING BATTERY

### **WARNING**

**Battery electrolyte is an acid and is poisonous and corrosive. Serious injury results from contact with the skin, eyes or clothing.**

If the electrolyte fluid is below level line, refill battery with distilled water.

# 9. PREPARATIONS FOR STORAGE




## DISCHARGE FUEL (NO SMOKING !)

### **WARNING**

Take extreme caution when draining gasoline. It is flammable.

Drain fuel from fuel tanks, carburetor and fuel line.



## ENGINE OIL

Change the engine oil with fresh oil.

Remove the spark plug, pour about 5 cc of engine oil into the cylinder, slowly start the engine for 2 or 3 seconds, and re-install the spark plug.



## CLEAN AND STORE

Remove the spark plug wires from the spark plugs.

Slowly turn the crankshaft until resistance is felt and leave it in that position.

Clean the engine thoroughly with an oiled cloth, cover the engine, and store the engine indoors in a well ventilated, low humidity area.

# 10. SPECIFICATIONS

| MODEL                              | EH63D   | EH64D              | EH65D              |
|------------------------------------|---|--------------------|--------------------|
| Type                               | Air-Cooled, 4-Stroke, V-Twin Cylinder, Horizontal P.T.O. shaft, OHV Gasoline Engine |                    |                    |
| Bore x stroke                      | 2-80 mm x 65 mm   |                    |                    |
| Displacement                       | 653 cm <sup>3</sup>   |                    |                    |
| Continuous Output<br>kW (HP) / rpm | 10.8 (14.5) / 3600  | 11.9 (16.0) / 3600 | 13.4 (17.0) / 3600 |
| Maximum Output<br>kW (HP) / rpm    | 13.4 (18.0) / 3600  | 15.3 (20.5) / 3600 | 16.4 (22.0) / 3600 |
| Max. Torque N·m (kgf·m) / rpm      | 43.3 (4.41) / 2000  | 44.4 (4.52) / 2200 | 45.6 (4.65) / 2500 |
| Direction of Rotation              | Counterclockwise as viewed from P.T.O. shaft side                                   |                    |                    |
| Lubricant                          | Automobile Engine Oil SAE #20, #30 or 10W-30 ;<br>Class SE, SF or higher            |                    |                    |
| Capacity of Lubricant              | 1.55 liter  |                    |                    |
| Fuel                               | Automobile Unleaded Gasoline  |                    |                    |
| Spark plug                         | NGK BP6ES   |                    |                    |
| Starting System                    | Electric Starter  |                    |                    |
| Dry Weight                         | 44 kg   |                    |                    |
| Dimension (L x W x H)              | 317 mm x 477 mm x 475 mm  |                    |                    |





 **FUJI HEAVY INDUSTRIES LTD.**

**INDUSTRIAL PRODUCTS DIV.**

2nd, Subaru Bldg.

1-1, Miyahara-cho, Omiya-shi,  
Saitama 330-0038, Japan

PHONE : (OMIYA 48) 653-5811

FACSIMILE : (OMIYA 48) 653-5691