

WARNING

The generator is designed to give safe and dependable service if operated according to instructions.
Do not operate the generator before you have read and understood the instructions. Failure to do so could result in death, personal injury or equipment damage.

Thank you for purchasing a Robin generator.

This manual covers operation and maintenance of the Robin generators. All information in this publication is based on the latest production information available at the time of approval for printing.

Pay special attention to statements preceded by the following words:

WARNING

Indicates a strong possibility of severe personal injury, loss of life and equipment damage if instructions are not followed.

CAUTION

Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE:

Gives helpful information.

If a problem should arise, or if you have any questions about the generator, consult an authorized dealer or service shop.

SYMBOLS AND MEANINGS

In accordance with the ISO standard, the specified symbols as shown in the following table are used for the products and this instruction manual.

| | |
|--|---|
| | Read the operator's instruction manual. |
| | Fire, naked flame and smoking prohibited. |
| | Caution, risk of electric shock. |
| | Do not connect the generator to the commercial power lines. |

1

| | | | |
|--|--|--|-------------------------------|
| | ON (Switch Engine) | | Engine oil |
| | OFF (Switch Engine) | | Add oil |
| | Alternating current | | Battery charging condition |
| | Direct current | | Choke (cold starting aid) |
| | Plus : positive polarity | | Engine start (Electric start) |
| | Minus : negative polarity | | Engine stop (Electric start) |
| | STOP-position of a bistable push control | | Fuel |
| | ON-position of a bistable push control | | Fast |
| | Protective earth (ground) | | Slow |
| | Fuse | | |

| | |
|--|---|
| | Rated power (kW) |
| | Rated frequency (Hz) |
| | Maximum site altitude above sea-level (m) |
| | Continuous power (kW) |
| | Rated voltage (V) |
| | Maximum ambient temperature (°C) |
| | Rated power factor |
| | Rated current (A) |
| | Mass (kg) |
| | |

3

- Be extremely careful that all necessary electrical grounding procedures are followed during each and every use. Failure to do so can be fatal.
- Do not contact the generator to a commercial power line. Connection to a commercial power line may short circuit the generator and ruin it or cause electric shock hazard. Use the transfer switch for connecting to domestic circuit. In the special case where the generator will be connected as stand by to the commercial network, the installation must be carried out by a qualified electrician taking into account the technical specifications of the generator and the commercial network.
- No smoking while handling the battery. The battery emits flammable hydrogen gas, which can explode if exposed to electric arcing or a naked flame. Keep the area well-ventilated and keep naked flames/sparks away when handling the battery.
- Engine becomes extremely hot during and for some time after operation. Keep combustible materials well away from generator area. Be very careful not to touch any parts of the hot engine especially the muffler area or serious burns may result.

5

2. SPECIFICATIONS

| | EXPERT 2410 X | EXPERT 3010 X | EXPERT 4010 X | EXPERT 5010 XL12 | MIXTES 4500 |
|---------------------------------|---------------------|---------------------|--|---------------------|---------------------|
| MAXIMUM OUTPUT ISO 8528 | 1,85 kW | 2,6 kW | 3,3 kW | 4,3 kW | 4,3 kW |
| RATED POWER FACTOR | | | 1 | | |
| RATED CURRENT | 8,0 A | 11,3 A | 14,3 A | 18,7 A | 18,7 A |
| MAXIMUM AMBIENT TEMPERATURE | | | 40 °C | | |
| MAXIMUM SITE ALTITUDE | | | 1000 m | | |
| NOMINAL VOLTAGE | | | 230V Single phase | | |
| ALTERNATOR TYPE | | | Brushless alternator, 2 poles | | |
| VOLTAGE REGULATION | | | Condenser | | |
| FREQUENCY | | | 50 Hz | | |
| EQUIPMENT | | | 2 Single phase sockets IP44 – 10/16A | | |
| PROTECTION | | | Sockets protected by a thermal circuit breaker | | |
| ENGINE MODEL | EX 13 | EX 17 | EX 21 | EX 27 | EX 27 |
| ENGINE TYPE | | | 4 stroke gasoline- OHC | | |
| COOLING SYSTEM | | | Air-cooled | | |
| MAXIMUM OUTPUT | 4,3 HP - 4000 rpm | 5,7 HP - 4000 rpm | 7 HP - 4000 rpm | 9 HP - 4000 rpm | 9 HP - 4000 rpm |
| PISTON DISPLACEMENT | 126 cm ³ | 169 cm ³ | 211 cm ³ | 265 cm ³ | 265 cm ³ |
| FUEL | | | Unleaded Petrol 95 | | |
| FUEL TANK CAPACITY VERSION X | 2,7 liters | 3,6 liters | 3,6 liters | 6,1 liters | 6,1 liters |
| FUEL TANK CAPACITY VERSION XL | - | - | - | 12 litres | - |
| AUTONOMY AT 3/4 LOAD VERSION X | 2 h 55 | 2 h 45 | 2 h | 3 h | 3 h |
| AUTONOMY AT 3/4 LOAD VERSION XL | - | - | - | 5 h 45 | - |
| STARTING SYSTEM | | | Recoil starter including rope system | | |
| ELECTRONIC OIL SENSOR | | | Serial | | |
| FRAME | | | Full steel frame | | |
| DIMENSIONS LxWxH | (600x470x415) mm | (600x470x415) mm | (600x470x415) mm | (765x570x520) mm | (765x570x520) mm |
| WEIGHT (DRY / GROSS) | (34 / 35) kg | (35 / 36) kg | (38,5 / 39,5) kg | (60 / 62) kg | (71 / 73) kg |

7



CHECK ENGINE FUEL

WARNING

Do not remove the fuel tank cap while the engine is running. Do not refuel while smoking or near naked flame or other such potential fire hazards. Otherwise fire accident may occur.

Check fuel level at fuel level gauge (standard with large fuel tanks). If fuel level is low, refill with unleaded automotive gasoline. Be sure to use the fuel filter screen on the fuel filter neck.

Fuel tank capacity : See table page 7.



WARNING

- Make sure you review each warning in order to prevent fire hazard.
- Do not refill tank while engine is running or hot.
- Close fuel cock before refueling with fuel.
- Be careful not to admit dust, dirt, water or other foreign objects into fuel.
- Wipe off split fuel thoroughly before starting engine.
- Keep naked flames away.

9

CHECKING COMPONENT PARTS

Check following items before starting engine :


- Fuel leakage from fuel hose, etc;
- Bolts and nuts for looseness;
- Components for damage or breakage;
- Generator not resting on or against any adjacent wiring.

WARNING

- Make sure you review each warning in order to prevent fire hazard.
- Keep area clear of flammables or other hazardous materials.
 - Keep generator at least 3 feet (1 meter) away from buildings or other structures.
 - Only operate generator in a dry, well ventilated area.
 - Keep exhaust pipe clear of foreign objects.
 - Keep generator away from naked flame. No smoking!
 - Keep generator on a stable and level surface.
 - Do not block generator air vents with paper or other material.

GROUNDING THE GENERATOR

- To ground the generator to the earth, connect the grounding lug of the generator to the grounding spike driven into the earth or to the conductor which has been already grounded to the earth.
- If such grounding conductor or grounding electrode is unavailable, connect the grounding lug of the generator to the grounding terminal of the using electric tool or appliance.




10

4. OPERATING PROCEDURES

WARNING

Check the oil level before each operations as outlined on page 8. Never change the accelerator position which is set at the factory.

1. STARTING THE ENGINE



If the engine fails to start after several attempts, repeat above procedures with choke knob returned to open.

- Do not fully pull out the rope.
- After starting, allow the starter handle to return to its original position while still holding the handle.

After the engine started, return the choke knob gradually to "OPEN" position.

Warm up the engine without a load for a few minutes.


2. USING ELECTRIC POWER

AC APPLICATION

This generator is thoroughly tested and adjusted in the factory. If the generator does not produce the specified voltage, consult your nearest Robin dealer or service shop.


Turn off the switch(es) of the electrical appliance(s) before connecting to the generator.

Insert the plug(s) of the electrical appliance(s) into the receptacle.




5. STOPPING THE GENERATOR

(a) Turn off the power switch of the electric equipment and unplug the cord from the receptacle of the generator.



(b) Allow the engine about 3 minutes to cool down at no-load before stopping.

(c) Turn the engine switch to the position "O" (OFF).



(d) Close the fuel cock.

6. OIL SENSOR

(a) The oil sensor detects the fall in oil level in the crankcase and automatically stops the engine when the oil level falls below a predetermined level.

(b) When engine has stopped automatically, switch off generator's no-fuse breaker, and check the oil level. Refill engine oil to the upper level as instructed on page 8 and restart the engine.

(c) If the engine does not start by usual, consult your nearest Robin dealer or service shop.

WARNING

Do not remove OIL SENSOR PROBE when refilling with oil. Remove oil filler cap on the opposite side of carburetor.

7. WATTAGE INFORMATION

Some appliances need a "surge" of energy when starting. This means that the amount of electrical power needed to start the appliance may exceed the amount needed to maintain its use. Electrical appliances and tools normally come with a label indicating voltage, cycles/Hz, amperage (amps) and electrical power needed to run the appliance or tool. Check with your nearest dealer or service center with questions regarding power surge of certain appliances or power tools.

- Electrical loads such as incandescent lamps and hot plates require the same wattage to start as is needed to maintain use.
- Loads such as fluorescent lamps require 1.2 to 2 times the indicated wattage during start-up.
- Loads for mercury lamps require 2 to 3 times the indicated wattage during start-up.
- Electrical motors require a large starting current. Power requirements depend on the type of motor and its use. Once

WARNING


Be sure to ground the generator if the connected electrical device is grounded.

Failure to ground unit could lead to electrical shock.

- Check the amperage of the receptacles, and be sure not to take a current exceeding the specified amperage.
- Be sure that the total wattage of all appliances does not exceed the rated output of the generator.

WARNING

Do not put foreign objects into the plug receptacle.



NOTE:

When the circuit breaker or no-fuse breaker turns off during operation, the generator is overloaded or the appliance is defective. Stop the generator immediately, check the appliance and/or generator for overloading or defect and have repaired as necessary by Robin dealer or service shop.

11

NOTE:

The following wattage chart is general guide only. Refer to your specific appliance for correct wattage.

To determine the total wattage required to run a particular electrical appliance or tool, multiply the voltage figure of the same appliance / tool by the amperage (amps) figure of the information can be found on a name plate which is normally attached to electrical appliances and tools.

| | Expert 2410X | Expert 3010X | Expert 4010X | Expert 5010X / XL12 | Mixtes 4500 |
|-----------------------------|--------------|--------------|--------------|---------------------|-------------|
| BULB / HEATING | 1800 W | 2600 W | 3200 W | 4300 W | 4300 W |
| HALOGEN / NEON | 2 X 500 W | 3 X 500 W | 4 X 500 W | 5 X 500 W | 5X500 W |
| HAND TOOLS WITHOUT VARIATOR | 1300 W | 1800 W | 2200 W | 3000 W | 3000 W |
| COMPRESSOR | 300 W | 500 W | 650 W | 800 W | 800 W |
| ELECTRIC MOTOR WITHOUT LOAD | 1/3 CV | 3/4 CV | 1 CV | 1,1 CV | 1,1 CV |
| WELDER | no | no | no | 70 A max | 70 A max |

12


8. MAINTENANCE SCHEDULE

| | VOLTAGE DROP IN ELECTRIC EXTENSION CORDS | | | | | | | | | | | | |
|-----------------------|--|----|-------------------|------------|-------|------|------|------|------|------|------|-----|--------------|
| Nominal cross section | No. | A | Allowable current | Resistance | /100m | 1A | 3A | 5A | 8A | 10A | 12A | 15A | Voltage drop |
| mm ² | No. | A | No./mm | | /100m | 1A | 3A | 5A | 8A | 10A | 12A | 15A | |
| 0,75 | 18 | 7 | 30/0,18 | 2,477 | 2,5V | 8V | 12V | - | - | - | - | - | |
| 1,27 | 16 | 12 | 30/0,18 | 1,486 | 1,5V | 5V | 7,5V | 12V | 15V | 18V | - | - | |
| 2,0 | 14 | 17 | 37/0,26 | 0,952 | 1V | 3V | 5V | 8V | 10V | 12V | 15V | - | |
| 3,5 | 12 à 10 | 23 | 45/0,32 | 0,517 | - | 1,5V | 2,5V | 4V | 5V | 6,5V | 7,5V | - | |
| 3,5 | 10 à 8 | 35 | 70/0,32 | 0,332 | - | 1V | 2V | 2,5V | 3,5V | 4V | 5V | - | |

13

3. CLEANING AND ADJUSTING SPARK PLUG


(a) If the plug is contaminated with carbon, remove it using a plug cleaner or wire brush.



(b) Adjust the electrode gap to 0.6 to 0.7mm.

4. CLEANING FUEL STRAINER

Dirt and water in the fuel are removed by the fuel strainer.



(a) Remove the strainer cup and throw away water and dirt.

(b) Clean the screen and strainer cup with gasoline.

(c) Tightly fasten the cup to main body, making sure to avoid fuel leak.

10. PREPARATION FOR STORAGE

The following procedures should be followed prior to storage of your generator for periods of 6 months or longer.

- Drain fuel from fuel tank carefully by disconnecting the fuel line. Gasoline left in the fuel tank will eventually deteriorate making engine-starting difficult.
- Remove the carburetor float chamber and also drain the carburetor.
- Change engine oil.
- Check for loose bolts and screws, tighten them if necessary.
- Clean generator thoroughly with oiled cloth. Spray with preservative if available.

NEVER USE WATER TO CLEAN GENERATOR !

- Pull starter handle until resistance is felt, leaving handle in that position.
- Store generator in a well ventilated, low humidity area.

11. TROUBLESHOOTING

When generator engine fails to start after several attempts, or if no electricity is available at the output socket, check the following chart.

When engine fails to start:


| | |
|--|--|
| Check if choke lever is in its proper position. | Set the choke lever to "CLOSE" position. |
| Check if fuel cock is open. | Set the choke lever to "CLOSE" position. |
| Check fuel level. | If empty, refill fuel tank making sure not to overfill. |
| Check if engine switch is in "O" (OFF). | Turn engine switch to "I" (ON). |
| Check to make sure generator is not connected to an appliance. | If connected, turn off the power switch on the connected appliance and unplug. |
| Check spark plug for loose spark plug cap. | If loose, push spark plug cap back into place. |
| Check spark plug for contamination. | Remove spark plug and clean electrode. |

When no electricity is generated at receptacle:

| | |
|---|---|
| Check to make sure no-fuse breaker is in the "I" (ON) position. | After making sure that the total wattage of the electrical appliance is within permissible limits and there are no defects in the appliance, turn the no-fuse breaker to the "I" (ON) position. If breakers continue to actuate, consult your nearest servicing dealer. |
| Check AC terminals for loose connection. | Secure connection if necessary. |
| Check to see if engine starting was attempted with appliances already connected to generator. | Turn off switch on the appliance, and disconnect cable from receptacle. Reconnect after generator has been started properly. |

If your generator still fails to start or to generate electricity, contact your nearest Robin dealer or service shop for further information or corrective procedures.

15



Commercial service Spare Parts and After sales service

FAX (33) 01 64 76 29 99 TEL (33) 01 64 76 29 80 FAX (33) 01 64 76 29 88

Standard

TEL (33) 01 64 76 29 50

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe - Bussy Saint Georges

Head office

7607 Marne la Vallée - Cedex 3 - FRANCE

Particulier Efrei 1 Bd de l'Europe -