



R210 GASOLINE ENGINE

FIG.1 HEAD SUBASSEMBLY, CYLINDER / PLUG, SPARK (E04)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E04-4	12131-Z140510-0000	GASKET, CYLINDER HEAD		1	1	
E04-5	12410-Z010220-H300	COVER SUBASSEMBLY, CYLINDER HEAD		1	1	
E04-6	12004-Z010110-0000	GASKET, CYLINDER HEAD COVER		1	1	
E04-7	17004-Z440110-0000	TUBE, BREATHER		1	1	
E04-8	90001-0612-01	BOLT		4	1	
E04-9	90204-Z010310-0000	STUD		2	1	
E04-10	90203-Z010110-0000	STUD		2	1	
E04-11	90502-1014-00	PIN		2	1	
E04-12	12003-Z010110-0000	BOLT, CYLINDER HEAD		4	1	
E04-13	30010-Z010210-0000	PLUG, SPARK		1	1	
E04-15	12140-Z040610-0000	HEAD SUBASSEMBLY, CYLINDER		1	1	

FIG.2 CRANKCASE. / GEAR ASSY, GOVERNOR. (E17)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E17-1	11310-Z140410-0000	CRANKCASE SUBASSEMBLY		1	1	
E17-2	37060-Z010110-0000	SENSOR, ENGINE OIL		1	1	
E17-3	16400-Z010110-0000	GEAR ASSY, GOVERNOR		1	1	
E17-7	16061-Z010110-0000	ARM, GOVERNOR		1	1	
E17-8	11007-Z010110-0000	BOLT, DRAIN PLUG		2	1	
E17-9	90408-Z010110-0000	WASHER		2	1	
E17-12	90548-0205-CL	BEARING		1	1	
E17-13	90682-Z300110-0000	SEAL, OIL		1	1	
E17-16	90408-Z010210-0000	WASHER, GOVERNOR GEAR		1	1	
E17-17	90501-Z010110-0000	PIN		1	1	
E17-18	90001-0614-01	BOLT		2	1	

FIG.3 COVER SUBASSEMBLY, CRANKCASE (E01)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E01-1	11411-Z010310-0000	COVER , CRANKCASE		1	0	
E01-2	90548-0205-CL	BEARING		1	1	
E01-3	90682-Z300110-0000	SEAL, OIL		1	1	
E01-4	11001-Z010310-0000	GASKET, CRANKCASE		1	5	
E01-5	90502-0812-00	PIN		2	1	
E01-6	15010-Z010120-Q500	DIPSTICK SUBASSEMBLY, OIL		1	1	
E01-8	15030-Z010120-Q500	PLUG SUBASSEMBLY, ENGINE OIL		1	1	
E01-9	90001-0832-01	BOLT		6	1	

FIG.4 ROD,CRANKSHAFT CONNETING (E03)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E03-1	13300-Z140330-0000	CRANKSHAFT ASSY.		1	1	

FIG.5 RING SET,OIL / ROD,CRANKSHAFT CONNETING (E03)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E04-2	13122-Z010110-0000	CLIP, PISTON PIN		2	1	
E04-3	13111-Z140110-0000	PISTON		1	1	
E04-4	13121-Z010110-0000	PIN, PISTON		1	1	
E04-5	13010-Z440110-0000	ROD, CONNECTING		1	1	
E04-7	13201-Z140110-0000	RING, THE FIRST		1	1	
E04-8	13202-Z140110-0000	RING, THE SECON		1	1	
E04-9	13210-Z140110-0000	RING SET, OIL		1	1	

FIG.6 TRAIN, VALVE / CAMSHAFT SUBASSEMBLY (E05)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E04-1	14200-Z300210-0000	CAMSHAFT ASSY.		1	1	
E04-3	12121-Z010110-0000	VALVE, EXHAUST		1	1	
E04-4	12111-Z010110-0000	VALVE, INTAKE		1	1	
E04-5	12112-Z010110-0000	SEAT, VALVE SPRING		1	1	
E04-6	12107-Z010110-0000	RETAINER, EXHAUST VALVE		1	1	
E04-7	12104-Z010110-0000	ROTATOR, VALVE		1	1	
E04-8	12101-Z010110-0000	GUIDE, SEAL		1	1	
E04-9	14081-Z040110-0000	TAPPET, VALVE		2	1	
E04-10	14071-Z010110-0000	LIFTER, VALVE		2	1	
E04-11	14090-Z010110-0000	PLATE SUBASSEMBLY, LIFTER STOPPER		1	1	
E04-12	14313-Z010110-0000	BOLT, VALVE ADJUSTING		2	1	
E04-13	14311-Z010110-0000	ROCKER, VALVE		2	1	
E04-14	14314-Z010110-0000	NUT, VALVE ADJUSTING		2	1	
E04-15	14312-Z010110-0000	NUT, VALVE LOCK		2	1	
E04-16	12103-Z010110-0000	SPRING, VALVE		2	1	

FIG.7 STARTER,RECOIL (E08)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E08-12	90001-0612-01	BOLT		4	1	
E08-13	28102-Z010110-0000	CAP, RECOIL STARTER REEL END		1	1	
E08-14	28200-Z010210-Q200	STARTER ASSY, RECOIL		1	1	

FIG.8 SHROUD / SHIELD,LOWER (E14)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E14-1	28110-Z010110-Y500	SHROUD		1	1	
E14-2	19304-Z010410-0000	SHROUD, CYLINDER BODY		1	1	
E14-3	19340-Z010120-0000	SHIELD,LOWER		1	1	
E14-4	37050-Z010210-0000	PROTECTOR, OIL		1	1	
E14-5	35540-Z010110-0000	SWITCH SUBASSEMBLY, STOP ENGINE		1	1	
E14-6	35541-Z010110-0000	WIRE, STOP ENGINE		1	1	
E14-7	35555-Z010120-0000	WIRE, STOP ENGINE SWITCH GROUNDING		1	1	
E14-8	90001-0612-03	BOLT		4	1	
E14-9	90001-0610-01	BOLT		2	1	
E14-10	90001-0616-01	BOLT		1	1	
E14-11	90740-Z010110-0000	COLLAR		1	1	
E14-12	90001-0610-01	BOLT		1	1	

FIG.9 CARBURETOR ASSY. (E11)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E11-1	16100-Z040610-0000	CARBURETOR ASSY.		1	1	
E11-2	17001-Z010210-0000	GASKET, AIR CLEANER		1	1	
E11-3	16001-Z300110-0000	GASKET, CARBURETOR		1	1	
E11-33	16003-Z010110-0000	PLATE, CARBURETOR INSULATOR		1	1	
E11-34	16002-Z300110-0000	GASKET, CARBURETOR INSULATOR		1	1	

FIG.10 CLEANER, AIR (F02)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E04-6	90001-0620-01	BOLT		1	1	
E04-13	17100-Z010210-0000	CLEANER, AIR		1	1	
E04-14	90305-0600-31	NET		2	1	

FIG.11 MUFFLER ASSY. (F04)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
F04-2	18001-Z300110-0000	GASKET, EXHAUST OUTLET		1	1	
F04-3	90303-0800-31	NUT		2	1	
F04-6	18100-Z010710-H300	MUFFLER ASSY.		1	1	

FIG.12 TANK ASSY, FUEL (F01)




REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
F01-1	16620-Z440120-Y500	TANK, FUEL		1	1	
F01-2	16652-Z010110-0000	STRAINER, FUEL		1	1	
F01-3	16730-Z010210-0300	COVER, FUEL TANK		1	1	
F01-4	16680-Z010110-0000	OUTLET SUBASSEMBLY, FUEL TANK OIL		1	1	
F01-5	90740-Z010210-0000	COLLAR		2	1	
F01-6	90686-Z010510-0000	TUBE, FUEL		1	1	
F01-7	90001-0630-01	BOLT		1	1	
F01-8	90305-0600-31	NUT		2	1	

FIG.13 FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL (E15)



REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E15-1	13501-Z010110-0000	NUT, FLYWHEEL		1	1	
E15-2	28002-Z010210-0000	PULLEY,STARTER		1	1	
E15-3	19352-Z010110-0000	IMPELLER		1	1	
E15-4	13510-Z010110-0000	FLYWHEEL SUBASSEMBLY		1	1	
E15-6	90001-0625-01	BOLT		2	1	
E15-8	30400-Z300110-0000	COIL, IGNITION		1	1	

FIG.14 CONTROL ASSY, THROTTLE (E13)



REF.NO.	PART NO	DESCRIPTION		Q'TY	Nb packet	
E13-1	16520-Z010420-0000	CONTROL ASSY, THROTTLE		1	1	
E13-2	16063-Z050120-0000	SPRING, GOVERNOR		1	1	
E13-3	16062-Z010110-0000	ROD, GOVERNOR		1	1	
E13-4	16012-Z010110-0000	SPRING, THROTTLE VALVE RETURNING		1	1	
E13-5	16070-Z010110-0000	SUPPORT SUBASSEMBLY, GOVERNOR		1	1	
E13-6	90001-0610-01	BOLT		2	1	
E13-15	16072-Z010110-0000	BOLT, GOVERNOR SUPPORT		1	1	
E13-16	90305-0600-31	NUT		1	1	