

# **GENERATOR**



# **Standard Equipment**

## Canopy Soundproofing

Removable soundproof canopy Painting canopy (RAL) in galvanized sheet steel Soundproofing with class 1 polyester material Handles with key lock and automatic closing Special baffles for air intake and air expulsion Inspection doors for controls and maintenance

#### **©** Exhaust

Exhaust rain cap Insulated exhaust pipes Internal residential muffler - 35dB(A)

### Tuel Supply

Single wall daily tank with bunded base Automatic shutdown system for low fuel level Fuel gauge

## Handling

Lifting hook integrated into the bearing structure Base frame with anti-overturning forklift pockets forkliftable on the short side

# **Base Frame**

Bunded base at 110% of fuel tank capacity Anti-vibrating mounting pads Battery compartment externally accessible for easy service

# Engine

High coolant temperature and low oil pressure shutdown system

External oil drain points

Engine liquids (oil and antifreeze)

Tropicalized radiator

Rotating parts protection

Electronic speed governor

### Alternator

AVR Automatic Voltage Regulator Impregnation for marine environment IP23

#### Panel & connection

**Emergency Stop button** Tamperproof panel IP55 Cable output from the bottom IP44 wiring Start-up battery (pre-charged) Grounding point

#### Documentation

CE conformity declaration User and Maintenance manual Wirings diagrams

### Normatives

All Generating sets are compliant to CE Marking 2014/30/UE Electromagnetic compatibility 2000/14/CE Noise Emission for outdoor use Factory-designed systems built according to ISO 9001:2015 CEI EN 60204-1:2018 - Electrical equipment of machines









# GENERATOR SILENTSTAR 80 T AI S5

# **Primary Data**

General Information		
Speed	RPM	1500
Frequency	Hz	50
PRP	kVA	80
PRP - Prime power ( $\cos \varphi = 0.8$ )	kW	64
LTP - Standby power	kVA	90
LTP - Standby power (cosφ= 0.8)	kW	72
Standard Voltage	V	400 / 230
Current (cosφ= 0.8)	А	115.61
Voltage for current calculation	V	400
cosφ		0.8
General Electrical Protection		
Circuit-breaker rated current	А	160
Туре		Non-Automatic circuit breaker on panel board
Circuit-breaker poles	N	4P
<b>♥</b> LWA		
LwA	dB(A)	91
Noise Level (+/- 3dB(A))		
Sound pressure level @ 7 m	dB(A)	66
Sound pressure level @ 1 m	dB(A)	75
Fuel Consumption		
		Diesel
Standard Fuel Tank capacity	L	250
Autonomy @ 75% load	h	20
Fuel consumption at 100% load	L/h	17.2
Fuel consumption at 75% load	L/h	12.7
Fuel consumption at 50% load	L / h	8.5
General Data		
Rated capacity	Ah	1x120
Auxiliary Voltage	V	12
Exhaust gas temperature	°C	740
Exhaust diameter	mm	80
Weight and Dimensions		
Dimensions (L x w x h)	cm	260 x 110 x 168
Weight with liquids (excluding optionals and fuel)	kg (± 3 %)	1455

# PRP

Net prime power 100%, permissible average load equal to or below < 80 % no time limitation, plus 10 % overload permissible for 1 running hour each 12 h.

# **LTP** (Limited Time Running Power)

ISO-8528-1 states that a LTP-rated generator set must provide power for up to 500 hours per year with the maintenance intervals and procedures being carried out as prescribed by the manufacturers.



# GENERATOR SILENTSTAR 80 T AI S5

gine
gine

Factory		FPT
Model		F36ETVP03.A85
Emissions stage		Stage 5
Speed governor		Electronic
Radiator	° C	50
Cooling	Туре	Liquid
Active net power	kW	74.3
Nominal net power	HP	101
Injection	Туре	Direct
Aspiration	Туре	Turbo
Numbers of cylinders	N	4
Cylinders arrangement		L
Bore	mm	102
Stroke	mm	110
Total displacement	L	3.6
Engine oil features		15W40-API CI-4/CH-4 ACEA E5-E7
Total oil capacity	L	9.5
Total coolant capacity	L	10.5
<u>~</u>		

# Cycle

Type 4 temps	Cycle	Туре	4 Temps	
--------------	-------	------	---------	--

# **Alternator**

mary brand will be used		
	Stamford	
	UCI224G	
kVA	85	
± %	1	
N°	4	
	3+N	
	Star Series	
	H (Outdoor Temp 40°C)	
%	90.2	
	Elastic disk	
	>= 300% (3In)	
IP	23	
	Self ventilating	
RPM	2250	
%	< 5	
	Diode bridge	
	kVA ± % N°	UCI224G     kVA

# Standard operating environmental conditions

Ambient temperature	° C	25
Relative Humidity	%	30
Max altitude	m	1000


Édition : 20240314




# **GENERATOR**

# **Control Systems on board QPE (+11)**







# **QPE** Automatic panel without switching on board

The QPE-C control panel represents the evolution of the panel for the control and management of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatlc guarantees to every type of functionality protection, analysis and control of the generating set in order to make the managment easy and efficient. Variant without transfer switch on board. ATS panel type QC as optional. The panel manages the QC panels directly or any other ATS panel.

Mechanical features	
Protection degree	
Battery charger	

Maximum output current	Α	2,5
Output DC voltage (selectable)	Vdc	12-24
Input AC voltage (selectable)	Vac	220-260
Frequency	Hz	50-60

# Data Communication


Data connection port	RS-485
Communication protocol	Mod-bus RTU-8N1

# **Control Systems on board QPE+ATS version (+10)**

# **QPE+ATS** Automatic panel with switching on board

The QPE-C control panel represents the evolution of the panel for the control and managment of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatic quarantees to every type of functionality protection, analysis and control of the generating set in order to make the managment easy and efficient. Variant without transfer switch on board. ATS panel type QC as optional. The panel manages the QC panels directly or any other ATS panel. This group is equipped with a 4-pole source changeover with electrical and mechanical interlocking.







# **Control Systems on Board QPE (+11)**

# WITH OPTIONAL 5 SOCKETS PANEL (O.G-USP-MPRB)





# **QPE** Automatic panel without switching on board

The QPE-C control panel represents the evolution of the panel for the control and managment of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatic guarantees to every type of functionality protection, analysis and control of the generating set in order to make the managment easy and efficient. Variant without transfer switch on board. ATS panel type QC as optional. The panel manages the QC panels directly or any other ATS panel..

# Mechanical Features

Protection degree

Battery charger		
Maximum output current	A	2.5
Output DC voltage (selectable)	Vdc	12-24
Input AC voltage (selectable)	Vdc	220-260
Frequency	Hz	50-60

55

### Data Communication

Data connection port	RS-485
Communication protocol	Mod-bus RTU-8N1

### Sockets Module

10-15 kVA	n°1 CE 2P+T -16A 230V / n°1 CE 2P+T -16A 230V / n°1 CE 3P+N+T 16A 400V
20 kVA	n°1 CE 2P+T -16A 230V / n°1 CE 2P+T -16A 230V / n°1 CE 3P+N+T 32A 400V
30-100 kVA	n°1 CE 2P+T -16A 230V / n°1 CE 2P+T -16A 230V / n°1 CE 3P+N+T 32A 400V / n°1 CE 3P+N+T 63A 400V
> 100 kVA	Contact Us

Édition: 20240314



# **GENERATOR** <u>SILEN</u>

# Control Module - Version QPE (+11)



Emergency to the Mains

Construction site/Rental

Microprocessor Logic

Programmable from display

Multiple display languages

STOP button

Alarm mute button

Fuel transfer pump activation button

# **ENGINE MEASURES**

Fuel tank level %

Engine oil pressure BAR (1)

Engine Coolant temperature °C (1)

Total run time

**Applications** 

Stand-alone

Self-production

Partial run time

Hours to maintenance

Battery voltage

Battery charging voltage

Start-ups counter

Engine speed (2)

Engine Oil temperature (2)

Cooler temperature (2)

Engine oil level (2)

Engine coolant level (2)

Engine coolant pressure (2)

Turbo pressure (2)

Fuel Consumption (2)

Tank autonomy - hrs (5)

Fuel remaining quatity (5)

Fuel used quantity (5)

#### ALTERNATOR MEASURES

Generator Voltage L1, L2, L3 Generator Voltage L1-N, L2-N, L3-N

Generator frequency

Generator current L1, L2, L3 Generator Apparent Power kVA

Generator Active Power kW

Generator Reactive Power kVAR

Generator accumulated power kWh

Power factor Cosfi

### **MAINS MEASURES**

Mains voltage L1, L2, L3 Mains voltage L1-N, L2-N, L3-N

Mains frequency

#### **COMMUNICATION PORTS**

Can-bus port

RS485 port with Mod-bus RTU communication

RS232 port for display connection

USB port for parameters saving and firmware update

**EQUIPMENT** 

Back-lit display

16 event log

START button

TEST button

Reset alarm button

Glow-plug activation button

#### PRE-ALARMS / ALARMS

Common Alarm

Fuel reserve (pre-alarm)

Low fuel level (alarm)

Tank overflow

Charge alternator failed (dinamo)

Low oil pressure (pre-alarm) (1)

Low oil pressure (alarm)

Oil sensor failed (alarm)

High coolant temperature (pre-alarm) (1)

High coolant temperature (alarm)

Low coolant temperature (pre-alarm)

Low water level (1)

Water in fuel (1) Battery undervoltage

Battery overvoltage

GS failure to start

GS failure to stop

Can-bus Failure

No Can-bus communication

Genset overload L1, L2, L3 phases

Genset short circuit

Genset overvoltage

Genset undervoltage

Genset high frequency

Genset low frequency

overspeed

Reverse power

Earth fault (pre-alarm)

Earth fault (alarm)

Block from password CAN communication Failed

Maintenance request

Emergency button pressed

Remote emergency active

Forced stop

External battery failed

Fuel theft

Genset negative phase sequence Mains negative phase sequence

Fuel theft protection

(1) Present with the sensor installed on engine

(2) Present according to the engine equipment and to the ECU type (ECU - Canbus)

(3) Present only with the residual current device mounted on genset board

(4) Present with optional expansion modules

(5) Present with special function activated

(6) Only with the optional of the automatic fuel refilling system on board

(7) Only in AMF mode

#### VISUALIZATIONS ON CONTROL MODULE/DISPLAY

MC4

AMF - MRS

Pre-alarms

Alarms

Model

Operating mode

Engine measures

Alternator measures

Mains measures

Date and time Operating mode

Genset status

Mains status

Mains contactor status

Genset contactor status

Digital Input and Output status Grounding current mA (3)

Grounding current threshold mA (3)

Delay time of differential protection (3)

Glow plugs status

#### CONTROL MODULE FUNCTIONS

Automatic start and stop when the Mains Fails (7)

Remote Start and Stop

Remote Start and Stop with key in OFF position Manual Start and stop

Emergency stop button on panel board

Remote emergency stop

Remote lock Remote test without load

Remote test on load

Scheduled start-ups

MODBUS commands (Start, Stop, Reset, Test)

### **CONTROL MODULE SPECIAL FUNCTIONS**

(on demand)

Automatic charging of an external battery Dummy load (4)

Load shedding (4) Redundant starter motor management

Fuel monitoring

GS battery Load test


Idle mode Service phone number indication

Variable speed Generator

Master / Slave mode



# SILENTSTAR 80 T AI S5





# GENERATOR SILENTSTAR 80 T AI S5

